

General Motors Transmission Mounts

	<p align="center">34053T - RWD</p> <p>Chevrolet Truck: 1982 - 1992 GMC Truck: 1987 - 1991</p> <p>Mounting Holes on Centerline, No Core Slots</p>		<p align="center">45053 - RWD</p> <p>Buick: 1976 - 88 Cadillac: 1981 - 85 Chevrolet: 1978 - 93 Oldsmobile: 1977 - 87 Pontiac: 1977 - 87</p>
	<p align="center">34053V - RWD</p> <p>Chevrolet Truck: 1983 - 1991 GMC Truck: 1983 - 1991</p> <p>Mounting Holes on Centerline, Core Slots on Sides</p>		<p align="center">46053HD - FWD, Front</p> <p>A Body: 1982 - On, except 2.5L with TH125 & TH440-T4 or 2.7L X Body: 1980 - 85</p>
	<p align="center">44053F - RWD</p> <p>Buick: 1975 - 79 Cadillac Brougham: 1991 - 94 Chevrolet: 1980 - 92 Oldsmobile: 1976 - 79 Pontiac: 1976 - 91</p>		<p align="center">46053AHD - FWD, Rear</p> <p>A Body: 1982 - On, except 2.5L with TH125 & TH440-T4 X Body: 1980 - 83</p>
	<p align="center">44053K - RWD</p> <p>Buick: 1980 Chevrolet: 1980, 85 - 86 Oldsmobile: 1977 - 80 Pontiac: 1977 - 89 Chevrolet Truck: 1982 - 92 GMC Truck: 1982 - 91</p> <p>Holes Slightly Off Centerline No Core Slots</p>		<p align="center">46053B - FWD, Rear</p> <p>Buick: 1985 - 89 "A" Body Chevrolet: 1985 - 90 Oldsmobile: 1985 - 90 Pontiac: 1985 - 90 U Body: 1990 - 95 w/3.1L Engine</p>
	<p align="center">44053L - RWD</p> <p>Buick: 1979 - 85 Chevrolet: 1979 Oldsmobile: 1978 - 79 Pontiac: 1978 - 87 Chevrolet Truck: 1983 - 92 GMC Truck: 1983 - 91</p> <p>Holes 3/4" off Centerline, Core Slots on Sides</p>		<p align="center">46053E - FWD</p> <p>J Body: 1982 - 94 L Body: 1987 - 91 N Body: 1988 - 91</p>
	<p align="center">44053U - RWD</p> <p>Universal General Motors Mount, Fits most applications for 8053F, 34053, 34053E, 44053</p>		<p align="center">46054 - FWD</p> <p>Buick: 1980 - 92 Chevrolet: 1980 - 91 Oldsmobile: 1980 - 92 Pontiac: 1980 - 92 End Diameters Approx. 2.240"</p>
			<p align="center">46054A - FWD</p> <p>Buick: 1982 - 86 Chevrolet: 1984 - 85 Oldsmobile: 1982 - 86 Pontiac: 1984 - 85 End Approx. 1.900" & 2.150"</p>



General Motors Mounts - Cont'd.

	<p style="text-align: center;">51053A - RWD</p> <p>Chevrolet Truck: 1985 - 91 GMC Truck: 1985 - 90</p> <p>Holes are 3/8" off Centerline Core Slots on Side</p>
	<p style="text-align: center;">51053B - RWD</p> <p>Chevrolet Truck 4X4: 1985 - 86 except 250, 87 - 96 with 6 & 8 Cyl. GMC Truck 4X4: 1985 - 86 except 250, 87 - 96 with 6 & 8 Cyl.</p>
	<p style="text-align: center;">52053 - FWD, Front</p> <p>Buick: 1985 - 91 Cadillac: 1985 - 91 Oldsmobile: 1985 - 91 Pontiac: 1987 - 91</p>
	<p style="text-align: center;">52053A - FWD, Rear</p> <p>Buick: 1985 - 91 Cadillac: 1985 - 91 Oldsmobile: 1985 - 91 Pontiac: 1987 - 91</p>
	<p style="text-align: center;">52053B - FWD, Rear (Hydraulic Mount)</p> <p>C Body: 85 - 87 w/3.0L, 3.8L, 4.3L and Cadillac with 4.1L, 1988 - 90 with 3.0L, 3.8L and 4.5L H Body: 1986 - 91 with 6 Cyl.</p>
	<p style="text-align: center;">52053C - FWD, Rear</p> <p>W Body: 1988 - 91 with 4 Cyl. 1988 - 95 with 3.1L 6 Cyl. 1991 - 94 with 3.4 & 3.8L</p>
	<p style="text-align: center;">52053D - Engine, Front</p> <p>A Body: All 1985 except with 2.5L or Diesel, 1986 - 1994 except 2.5L with TH125 or TH440-T4 U Body: All 1990 - On</p>

Ford Transmission Mounts

	<p style="text-align: center;">26053 - RWD</p> <p>Ford: 1962 - 80 Lincoln: 1977 - 80 Mercury: 1966 - 80</p>		<p style="text-align: center;">49053C - Engine, Right Rear</p> <p>Ford: 1986 - 90 Taurus with 3.0L Engine Mercury: 1986 - 90 Sable with 3.0L Engine 2.125" Bolt Center</p>
	<p style="text-align: center;">26053T - RWD</p> <p>Ford Truck: 1966 - 80 6 3/4 Overall Length, 3" Wide, 2 1/2 from Base to Top Bolt Hole Center Line</p>		<p style="text-align: center;">53053 - Engine, Right Rear</p> <p>Ford: 1988 - 94 Taurus with AXOD and 3.8L Engine Mercury: 1988 - 94 Sable with AXOD and 3.8L Engine Lincoln: 1988 - 94 Continental with AXOD and 3.8L Engine</p>
	<p style="text-align: center;">26053TA - RWD</p> <p>Ford Truck: 1975 - 91 Bronco: 1975 - 86 Rectangular Base</p>		<p style="text-align: center;">53053A - Engine, Right Front</p> <p>Ford: 1986 - 90 Taurus with 3.0L Engine Mercury: 1986 - 90 Sable with 3.0L Engine 2.375" Bolt Center</p>
	<p style="text-align: center;">36053 - RWD</p> <p>Ford: 1977 - 91 with V8 Lincoln: 1980 - 91 with V8 Mercury: 1977 - 91 with V8 Base has Notches in 2 Corners</p>		<p style="text-align: center;">53053B - Engine, Right Front</p> <p>Ford: 1988 - 94 Taurus with 3.8L Engine Mercury: 1988 - 94 Sable with 3.8L Engine Lincoln: 1988 - 94 with 3.8L Engine</p>
	<p style="text-align: center;">47053 - RWD</p> <p>Ford: 1978 - 94 with AOD Mercury: 1978 - 94 with AOD Bolt Holes in Center</p>		<p style="text-align: center;">53053C - Engine, Right Rear</p> <p>Ford: 1991 - 95 Taurus with 3.0L Engine Mercury: 1991 - 95 Sable with 3.0L Engine</p>
	<p style="text-align: center;">49053A - Trans, Left Rear</p> <p>Ford: 1984 - 90 Escort, 1984 - 85 Tempo with ATX Mercury: 1984 - 87 Lynx w/ ATX 1984 - 85 Topaz with ATX</p>		<p style="text-align: center;">53053D - Engine, Right Rear</p> <p>Ford: 1986 - 87 Taurus with 2.5L Engine Mercury: 1986 - 87 Sable with 2.5L Engine 1.950" Bolt Center</p>
	<p style="text-align: center;">49053B - Trans, Left Front</p> <p>Ford: 1986 - 91 Tempo w/ATX, Front & Rear, 92 - 94 Tempo Left Rear Mercury: 1986 - 91 Topaz w/ ATX Front & Rear, 92 - 94 Tempo Left Rear</p>		<p style="text-align: center;">53053E - Engine, Right Front</p> <p>Ford: 1991 - 92 Taurus with 3.0L Engine Mercury: 1991 - 92 Sable with 3.0L Engine Stud & Bracket</p>

Ford Mounts - Cont'd.

	<p style="text-align: center;">53053F - Trans, Side</p> <p>Ford: 1990 - 94 Taurus with 3.0L 88 - 94 with 3.8L, 93 - 94 with 3.2L Mercury: Sable 90 - 94 with 3.0L 88 - 94 with 3.8L</p>
	<p style="text-align: center;">66053 - RWD</p> <p>Aerostar: All 1986 - 88 Ranger: 1985 - 94 with Manual Transmission</p>
	<p style="text-align: center;">66053A - RWD</p> <p>Bronco: 85 - 86 with 6 Cyl., 87 - 96 with 6 & 8 Cyl., Bronco II: 84 - 94 2WD, Ranger: 82 - 84, 91-97 4WD, E Series: 1988 - 95 6 Cyl. 2WD F Series: 1987 - 93 2WD Explorer: 1991 - 97 4WD with V6</p>
	<p style="text-align: center;">66053B - RWD</p> <p>Aerostar: All 1988 -97 Bronco: 1985 - 94 with 4 Cyl Bronco II: 1985 - 94 with 4WD Explorer, Mountaineer: 91 On 2WD Ranger: 82 - 84 4WD 85 - On 2WD E & F Series: 87 - 94 6 Cyl. 4WD</p>
	<p style="text-align: center;">84053 - FWD</p> <p>Ford: 91 -96 Escort, EXP with 1.8L & 1.9L Engines Mercury: 91 - 96 Lynx, LN7 with 1.8L & 1.9L Engines</p>

Chrysler Transmission Mounts / Transfer Case Mounts

	<p>22053HD - RWD</p> <p>Chrysler: 1969 -78, 1985 - 89 Dodge: 1969 - 77, 1985 - 89 Plymouth: 1969 - 77, 1985 - 89</p>		<p>48053F- Engine, Front</p> <p>Chrysler: 1990 - On Dodge: 1990 - On Plymouth: 1990 - On</p>
	<p>K22053E - RWD</p> <p>Trans Mount (2 Per Vehicle) Dakota: 4X4 1 Ton: 1986 - On Power Ram: 1985 - On Ram Charger 4X4: 1985 - On</p>		<p>48053H - Engine, Right</p> <p>Most Chrysler: 1985 -89 Most Dodge: 1985 - 89 Most Plymouth: 1985 - 89</p>
	<p>22053F - RWD</p> <p>2WD Ram Pickup, Van & Wagon 1988 - On: 2WD Ram Charger 1989 - On: Dakota 1/2 Ton 2WD 1986 - 94 Except 5.9L Diesel</p>		<p>48053J - Engine Right</p> <p>Most Chrysler: 1990 - On Most Dodge: 1990 - On Most Plymouth: 1990 - On</p>
	<p>32054 - FWD</p> <p>Trans. Insulator: Dodge, Chrysler And Plymouth with 3.3L and 3.8L 6 Cylinder Engines, 1989 - On</p>	<p>Transfer Case Mounts</p>	
	<p>48053B - Engine Front</p> <p>Chrysler: 1982 - 90 Dodge Cars: 1982 - 90 Plymouth Cars: 1982 - 90</p>		<p>21053 - RWD</p> <p>Upper Transfer Case Mount Chevrolet Truck: 1955 - 90 GMC Truck: 1955 - 90</p>
	<p>48053D - FWD</p> <p>Chrysler: 1985 - 90 with 4 Cyl. Dodge: 1985 - 90 with 4 Cyl. Plymouth: 1985 - 90 with 4 Cyl.</p>		<p>21053A - RWD</p> <p>Lower Transfer Case Mount Chevrolet Truck: 1955 - 90 GMC Truck: 1955 - 90</p>
	<p>48053E - FWD</p> <p>Chrysler: 1990 - 95 with 4 Cyl. Dodge: 1990 - 95 with 4 Cyl. Plymouth: 1990 - 95 with 4 Cyl.</p>		