





# Toyota A440F, A442F (4WD 4-Speed)

VEHICLE MODEL	YEARS	DRIVE TRAIN	TRANS. TYPE	
Toyota Land Cruiser .....	1986-92 .....	4WD .....	<b>A440F</b>	
Toyota Land Cruiser .....	1993-95 .....	4WD .....	<b>A442F</b>	
ILL. NO.	PART NUMBER	PER CAR	DESCRIPTION	YEARS
<b>MASTER BOX KITS</b>				
---	<b>K1100F-S</b>		Master Kit (w/o Steels) ..... <b>Transmission Section</b> .....	1986-92
---	<b>K1100FC-S</b>		Master Kit (w/o Steels) ..... <b>Transmission Section</b> .....	1993-95
<b>Steel Plate Kits:</b>				
---	<b>K1100F-9</b>		Steel Plate Kit ..... <b>Transmission Section</b> .....	1986-5/90
---	<b>K1100F-9A</b>		Steel Plate Kit ..... <b>Transmission Section</b> .....	6/90-92
---	<b>K1100FC-9</b>		Steel Plate Kit ..... <b>Transmission Section</b> .....	1993-95
<b>OVERHAUL KITS</b>				
---	<b>K11900F</b>	1	Overhaul Kit ..... <b>Transmission Section</b> .....	1986-95
---	<b>K11900FT</b>	1	Overhaul Kit ..... <b>Transfer Case Section</b> .....	1986-1/90
<b>GASKET AND RUBBER COMPONENTS</b>				
1E	<b>11170F</b>	1	Pan Gasket ..... <b>Duraprene</b> .....	1986-95
2E	<b>11120F</b>	1	Oil Filter Gasket .....	1986-95
<b>METAL CLAD SEALS</b>				
10A	<b>65526C</b>	1	Front Pump .....	1986-95
---	<b>68504</b>	2	Manual Lever ( <b>Cross Shaft</b> ) .....	1986-95
---	<b>67509</b>	1	Speedometer .....	1986-95
<b>CLUTCH PLATES (TRANSMISSION SECTION)</b>				
20A	<b>11304F</b>	3	Overdrive Direct Friction ..... <b>46T, .082" - 4.990" O.D.</b> .....	1986-95
21A	<b>11305F</b>	3	Overdrive Direct Steel ..... <b>10T, .070" - 4.010" I.D.</b> .....	1986-95
23B	<b>11308F</b>	3	Overdrive Brake Friction ..... <b>70T, .079" - 6.887" O.D.</b> .....	1986-92
23B	<b>11310F</b>	3	Overdrive Brake Friction ..... <b>75T, .075" - 7.230" O.D.</b> .....	1993-95
24B	<b>11309F</b>	3	Overdrive Brake Steel ..... <b>6T, .095" - 6.004" I.D.</b> .....	1986-92
24B	<b>11311FC</b>	2	Overdrive Brake Steel ..... <b>6T, .095" - 6.405" I.D.</b> .....	1993-95
24B	<b>11311FD</b>	1	Overdrive Brake Steel ..... <b>6T, .158" - 6.405" I.D.</b> .....	1993-95
26C	<b>11304F</b>	6-7	Forward (Front) Friction ..... <b>46T, .082" - 4.990" O.D.</b> .....	1986-95
27C	<b>11305F</b>	6-7	Forward (Front) Steel ..... <b>10T, .070" - 4.010" I.D.</b> .....	1986-95
30C	<b>11304F</b>	5	Direct (Rear) Friction ..... <b>46T, .082" - 4.990" O.D.</b> .....	1986-95
31C	<b>11305F</b>	5	Direct (Rear) Steel ..... <b>10T, .070" - 4.010" I.D.</b> .....	1986-95
33C	<b>11308F</b>	4-5	Intermediate (Brake No. 1) Friction ..... <b>70T, .079" - 6.887" O.D.</b> .....	1986-95
34C	<b>11309F</b>	4	Intermediate (Brake No. 1) Steel ..... <b>6T, .095" - 6.004" I.D.</b> .....	1986-5/90
34C	<b>11309FC</b>	7	Intermediate (Brake No. 1) Steel ..... <b>6T, .071" - 6.004" I.D.</b> .....	6/90-92
34C	<b>11309F</b>	5	Intermediate (Brake No. 1) Steel ..... <b>6T, .095" - 6.004" I.D.</b> .....	1993-95
36E	<b>11321F</b>	6	1st and Reverse Friction ..... <b>70T, .062" - 6.887" O.D.</b> .....	1986-95
37E	<b>11322F</b>	6	1st and Reverse Steel ..... <b>16T, .071" - 5.990" I.D.</b> .....	1986-92
37E	<b>11322FA</b>	6	1st and Reverse Steel ..... <b>16T, .095" - 5.999" I.D.</b> .....	1993-95

# Toyota A440F, A442F (4WD 4-Speed)

Toyota A440F / A442F

ILL. NO.	PART NUMBER	PER CAR	DESCRIPTION	YEARS
<b>BUSHINGS</b>				
---	<b>K11980F</b>	1	Bushing Assortment Kit .....	1986-95
40A	<b>11005F</b>	1	Pump Bushing .....	1986-95
<b>TRANSMISSION OIL FILTERS</b>				
50E	<b>11600F</b>	1	2" Thick Oil Filter ..... <b>Deep Pan</b> .....	1986-92
50E	<b>11601F</b>	1	5/8" Thick Oil Filter ..... <b>Shallow Pan</b> .....	1986-92
50E	<b>11602F</b>	1	Oil Filter ..... <b>A442F</b> .....	1993-95
51E	<b>ATK-107</b>	1	Oil Filter Kit ( <b>2" Filter</b> ) ..... <b>Deep Pan</b> .....	1986-92
51E	<b>ATK-145</b>	1	Oil Filter Kit ( <b>5/8" Filter</b> ) ..... <b>Shallow Pan</b> .....	1986-92
51E	<b>ATK-205</b>	1	Oil Filter Kit ..... <b>A442F</b> .....	1993-95
<b>SPRAGS</b>				
60A	<b>11815F</b>	1	Overdrive Sprag .....	1986-95
61D	<b>11813F</b>	1	Low Sprag .....	1986-95

**Notes:**