

Hondamatic 2 & 3-SPEED (Not Illustrated)

MASTER BOX KITS				
---	K6800-S	1		Master Kit (w/o Steel Plates) 1975-80
---	K6800-9	1		Steel Plate Sub-Kit 1975-80
---	K6800A-S		1	Master Kit (w/o Steel Plates) 1980-85
---	K6800A-9		1	Steel Plate Sub-Kit 1980-85
OVERHAUL KITS AND GASKET SETS				
---	K68900	1		Overhaul Kit 1975-80
---	K68900A		1	Overhaul Kit 1980-85
---	K68900A-1		1	Gasket and Seal Kit 1980-85
METAL CLAD SEALS				
--	68502	1	1	Torque Converter 1975-85
---	68505	1		Speedometer Gear Housing 1975-80
---	68501	1	1	Converter Housing (Right Axle) 1975-85
---	70551	1	1	Case Housing (Left Axle) 1975-85
---	68504	1	1	Cross Shaft 1975-85
---	68506		1	Throttle Valve Lever 1980-85
SEALING RINGS				
---	K68901	1		Sealing Ring Kit 1975-80
---	68201	4		Low & Drive Clutch 1975-80
---	68200	1		Main Shaft 1975-80
---	68203		2	Main Shaft 1980-85
CLUTCH PLATES				
---	68304	8		Low & Drive Friction 1975-80
---	68305	8		Low & Drive Steel 1975-80
---	68304A		9	1st, 2nd, 3rd Friction 1980-85
---	68305A		9	1st, 2nd, 3rd Steel 1980-85
MISCELLANEOUS				
---	68600	1		Oil Filter See Page 5.2-6 for Visual Identification 1975-80
---	68600A		1	Oil Filter See Page 5.2-6 for Visual Identification 1980-85
---	68814D		1	Sprag Assembly 1980-85
NOTES:				